

Flow-Converter UNICON-DF

Flow measurement with pulse sensors

Features

- Measuring range programmable
from -99999 ... 99999 Digit
- Measuring unit programmable
e.g. l/s; l/min; l/h; m³/s....;
(US)gal/s....; (US)bar(rel)/s....
- Totalizers programmable
- Additional 2. measuring input
- Output 4 ... 20mA, loop powered
- Pulse-output for external evaluation
- LCD-Text Display
- 2 electronic alarm outputs, voltage free
- Simulation mode for flow (manual operation)
- Protection IP65



Fieldcase
100x100x60 mm (BxHxT)

General

The Flow-Converter UNICON-DF is used in food technology, chemical and pharmaceutical industry and water technology. In connection with any type of pulse flow sensor the flow rate can be measured, displayed and converted in a 4 ... 20 mA signal. An additional feature is the summation function (totalizer). Using the alarm outputs a quantity dosage can be realized.

Short information

Programming	The front panel keypad can be used to program all designated functions.
Measurement value	The measured values are averaged continuously over a period of 0.1 ... 10 s (programmable). This period limits the minimum input frequency, because at least two impulses must arrive within.
Totalizers	2 counters (totalizers) are available. The daily totalizer can be reset manually. Automatic reset takes place by cutting off power. The overall totalizer is zero voltage protected and can only be reset by a special code (password protection).
Pulse output	Allows an external summation of flow quantity.
Alarm outputs	Switching performance of the alarm outputs is programmable as minimum or maximum function. The state of the alarm outputs is shown in the LCD-Display

Technical data

Power supply

Supply voltage : 12 ... 30 V DC, loop powered
Using Namur sensors or sensors with NPN- and PNP output with power demand > 5 V/ > 2 mA a separate supply is necessary (12 ... 30 V DC).

Working temperature : -10 ... 55 °C

Isolation : between analog output/alarm output 1/alarm output 2/impulse output/external sensor supply

Rated voltage : 500 V DC, between analog output/alarm output 1/alarm output 2/impulse output/external sensor supply

Measuring input

Typ : Inductive transmitter (coil), Namur-sensor or e.g. Hall-Sensor (rectangular pulse) programmable. Alternatively extern pulses 0/5 ... 24 V DC.

Input coil : switching threshold programmable from ± 5 ... ± 1000 mV

Input NPN-Sensor : low level < 0.9 V , high level > 2.1 V pull-up-resistor 20 k Ω

Input PNP-Sensor : low level < 0.9 V , high level > 2.1 V pull-down-resistor 20 k Ω

Input Namur : low level < 1.4 mA , high level > 1.8 mA , hysteresis ca. 0.4 mA

Input frequency : 0.1/10 ... 2000 Hz (depends on the programmed measuring interval)

Flow output

Current output : 4 ... 20 mA, external load R_A [Ω] $\leq \frac{\text{Supply voltage} - 12 \text{ V}}{0,02 \text{ A}}$

Accuracy : < 0.1 % of the measuring value

Temperature coefficient : < 0.01 %/ °C

Pulse output : 12 ... 30 V DC, load max. 60 mA, short circuit protected

Pulse width : 100 ms

Frequency : max. 5 Hz

Quantity/Volume per pulse programmable from 1 ... 99999 digit

Alarm outputs

Transistor : 12 ... 30 V DC, load max. 60 mA, short circuit protected

Voltage drop : < 2 V (at max. load)

Display

Flow : LCD- dot matrix, 4.9 mm character height, 2 lines each 16 characters

- Unit : -99999 ... 0 ... 99999 digit, max 3 decimal points

- Unit : l/s, l/min, l/h; m³/s, m³/min, m³/h; (US)gal/s, (US)gal/min, (US)gal/h; bar(rel)/s,

bar(rel)/min, bar(rel)/h

Totalizer : -9999999 ... 0 ... 9999999 digit, max. 3 decimal points

- Unit : l, m³, (US)gallon, barrel

- Storage : Daily totalizer not voltage safe

Overall totalizer voltage safe

Case

Material : Field-case
: case polyamide with fibre-glass PA6-GF/GK 15/15
front foil polyester


Dimensions : 100 x 100 x 60 mm (WxHxD)

Weight : max. 360 g


Electrical connection : Screw terminal pressure plate, 2.5 mm² flexible, 4 mm² wire

Protection : IP65, terminals IP20 finger safe acc to German BGV A3

Legend (open lid)




Dimensions



Connection diagram


Terminals output




* For supplying the converter use terminals (9) and (10) as shown. If the converter is used for monitoring only, terminals (9) and (10) must be connected direct to the supply voltage.

** Separate supply voltage over the terminals 7 and 8 only when using Namur sensors (according to DIN EN60947) or sensors with NPN- or PNP output with power demand $U_b > 5 \text{ V} / > 2 \text{ mA}$.

Terminals sensor inputs



Panel controls and indicators



Instructions

Operating of the device is arranged in 2 levels. The desired parameter can be called by button . For selection within a parameter use buttons  and .

Button combinations (press buttons at the same time):

-  +  1 Parameter back
-  +  Parameter to "0" or minimum value

When the power supply is switched on, the UNICON initializes itself. The display shows the device type UNICON-CL and software version. After initializing the current measurement values are displayed.

The **configuration level** is called-up by pressing the button . Now all the parameters defining the function of the UNICON can be programmed. After pressing the button  again, the entered data will be stored.

When the configuration is finished, or when no button is pressed for more than 120 seconds, the program jumps back to the working level. Leaving the **configuration level** is possible at any time when pushing the button  for 2 seconds.

Error code:

Display is flashing the measured signal exceeds the programmed range



After installation, the device must be configured for the intended use. See page 6.

Programming

Notes to representation




Parameter is only displayed if configured




Parameter is only displayed if included (see order code)

Note! During the configuration only those parameters will be displayed, which are not excluded by other parameter settings.

Working level



Configuration level



continue page 7

Display**Description** (the display graphic contents factory settings)

Sensor specifications for the K-factor see type plate or data-sheet of the installed sensor.

Decimals K-factor input 1

Selection with buttons ▲ and ▼.

4
KF1 decimals
n=0...4 n=2



5
K-factor inp.1
K=10.00 pulses/l



6
Measuring inp.2
■OFF □ON



7
Sensor2 ■Coil
□NPN □PNP □Namur



8
Sensitiv. inp.2
±100mV



9
KF2 decimals
n=0...4 n=2



10
K-factor inp.2
K=10.00 pulses/l



11
Inp. combination
■I1+I2 □I1-I2



12
Unit flow-rate
▲ l/min ▼

**K-factor input 1, stated in pulses/litre (see sensor data sheet)**

Setting possible from 1 ... 99999 digit with buttons ▲ and ▼.

Measuring input 2 (only model type 2)

Selection with buttons ▲ and ▼.

Measuring principle input 2

Coil, NPN, PNP or Namur-Sensor.

Selection with buttons ▲ and ▼.

For sensors with push-pull output, PNP must be selected.

Input sensitivity (level indication) input 2 for Coil mode

Setting possible from ±5 ... ±1000mV with buttons ▲ and ▼.

Note: The trigger level should be selected as large as possible in order to avoid fault measurements.

Decimals K-factor input 2

Selection with buttons ▲ and ▼.

K-factor input 2, stated in pulses/litre (see sensor data sheet)

Setting possible from 1 ... 99999 digit with buttons ▲ and ▼.

Input combination

I1+I2 = Addition of the inputs.

I1-I2 = Subtraction of the inputs

Selection with buttons ▲ and ▼.


Measuring unit flow-rate

l/s, l/min, l/h; m³/s, m³/min, m³/h; (US) gal/s, (US) gal/min, (US) gal/h; bar(rel)/s, bar(rel)/min, bar(rel)/h


Selection with buttons ▲ and ▼.

In case of modification measuring range, volume quantity/pulse and alarm set-points will be converted automatically

continue page 8




Display**Description** (the display graphic contents factory settings)

22


Common-totalizer reset

Reset to "0" by pushing buttons ▲ + ▼ for 2 seconds.

23


Alarm function AL1

Deactivated (OFF), flow (FR), daily-totalisator (DT) or overall-totalisator (OAT). Selection with buttons ▲ and ▼.

24


Switching function AL1

Selection with buttons ▲ and ▼.

25


Setpoint AL1

Setting possible in the programmed measuring range with buttons ▲ and ▼.

26



Hysteresis AL1

Setting possible from 1 ... 65535 Digit with buttons ▲ and ▼.

27


Alarm function AL2

Deactivated (OFF), flow (FR), daily-totalisator (DT) or overall-totalisator (OAT). Selection with buttons ▲ and ▼.

28


Switching function AL2

Selection with buttons ▲ and ▼.

29


Setpoint AL2

Setting possible in the programmed measuring range with buttons ▲ and ▼.


30


Hysteresis AL2

Setting possible from 1 ... 65535 Digit with buttons ▲ and ▼.

30



continue page 10



Description (the display graphic contents factory settings)

Pulse output for external evaluation

Selection with buttons ▲ and ▼.



Volume quantity per pulse

It is possible to set an alarm output with value "0" for indication of negative flow-rate (via input 2).

Unit and decimals are copied from programmed flow parameters.

Setting possible from 1 ... 99999 Digit with buttons ▲ and ▼.




Simulation of flow-rate (manual mode)

Start value = actual value.


Setting possible within the programmed measuring range with buttons ▲ and ▼.

Note: This parameter is not automatically exited after 120s




Adjustment of the process output

Selection with buttons ▲ and ▼.




Correction initial value output flow-rate

Setting possible from 3.500 ... 5.000mA with buttons ▲ and ▼.



Correction end value output flow-rate


Setting possible from 19.000 ... 21.000mA with buttons ▲ and ▼.




Programming lock.

If this parameter is set to lock condition, only setpoints of the alarm outputs AL1, AL2 and the totalizers will be displayed in the working level.

Press button ▲ and ▼ for min. 2 seconds



Parameter for factory setting



Return to working level

Error codes

Display	Description and remedy
Write protect!!	An entered parameter data could not be stored because write protection is activated by internal slide switch to position ON. Set switch to position OFF and modify again.
Wrong Code!!	Wrong code setting for totalizer programming (Password protection) After approx. 3 s an reset occurs.
XX Param. error please check	While examination of parameter memory XX errors were detected. Incorrect parameters were put back to factory setting. Check parameters and program again if necessary.
XX Param. error check 4-20mA too	While examination of parameter memory XX errors were detected. Incorrect parameters were put back to factory setting. Check parameters and program again if necessary. However the adjusted values for flow process output 4-20mA must be examined in the factory.

Comments to password protection

Access to totalizers can be locked by numeric code (password).

At factory the code is set to "0". Without changing the code, no password protection is active

Entering a 4-digit number (password) in parameter 18 "Adj. total code" will activate password protection.

Now calling again the totalizer parameters is only possible when entering the password in the menu "Konf. Totalisat."

If working again with code number 0, programming continues with next step not concerning totalizer functions.

Entering a wrong code number, display shows "Wrong code". After 3 seconds the device will be reset. Configuration must be started again.

Attention!

Forgetting the password code makes factory repair necessary!!

Ordering code:

UNICON-DF - 1. - 2. - 3.

1. Model

- 1 Measuring principle inductive sensor (Coil) Namur-sensor,
NPN- and PNP-sensor (pulses),
Output 4...20mA,
1 impulse output for extern evaluation,
2 electronic alarm outputs,
Supply voltage 12 ... 30V DC, loop powered
- 2 Feature as before, but
additional input for addition / subtraction,
(incl. 2-nd cable gland M12x1.5 in the housing)

2. Mounting

- 02 Field mounting
Connection of the flow sensor with separate connection cable

3. Options

- 00 without option