

INSTALLING USB DRIVER IN HD31

The USB port of the instrument HD31 can operate in two modes:

- **HID** (Human Interface Device)
- **VIRTUAL COM.**

HID mode does not require USB driver installation: when you connect the instrument to your PC, Windows® operating system automatically recognizes the instrument and uses the drivers already included in the operating system.

VIRTUAL COM mode requires, on the contrary, USB drivers to be installed. The driver installation is requested by Windows® operating system the first time the instrument in VIRTUAL COM mode is connected to your PC. When the operating system asks you to install the USB drivers, select the driver installation option through a specific path, then select **DeltaOHM_VirCOMDriver** folder included in the installation folder of DeltaLog9 software (DeltaLog9 software needs to be previously installed, the software installation folder is usually "C:\DeltaLog9", if this has not been changed during installation).

Note: if during the installation of the USB drivers a system protection message appears, select " *Install driver software*".